AR88.70-P-9000GH	Remove/install complete outside rearview mirror	12.2.97


MODEL 163.113 /128 /136 /154 /157 /172 /174 /175

Illustrated up to VIN A289564, X754619

1 *Paneling*
2 *Screw*
3 *Nuts*

M21/1 *Left electrically adjustable and heated outside mirror*

M21/1x1 *Left electrically adjustable and heated outside mirror connector*



P88.70-0252-06

	Removing and installing		
1	Press off paneling (1) with assembly wedge	As of VIN A289565, X754620: If present, disconnect connector from loudspeaker. Assembly wedge	*110589035900
2	Unscrew screw (2)		
3	Unscrew nut (3)	Secure outside rearview mirror against falling down **Installation:** Up to VIN A289564, X754619 fasten mounting lug for connector for left electrically adjustable and heated outside rearview mirror (M21/1x1) or for connector for right electrically adjustable and heated outside rearview mirror on bottom stud bolt.	
4	Separate connector for left electrically adjustable and heated outside rearview mirror (M21/1x1) or connector for right electrically adjustable and heated outside rearview mirror.		
5	Remove left electrically adjustable and heated outside rearview mirror (M21/1) or right electrically adjustable and heated outside rearview mirror		
6	Install in the reverse order		



110 589 03 59 00

Assembly wedge